

ALS-960



POWER SWITCH

LINE LEVEL TRANSMIT ON/OFF

AUX/TRANSMIT ON/OFF

RF SIGNAL TRANSMIT

AF SIGNAL TRANSMIT

PEAK INDICATOR

CHANNEL SET

UNBALANCED LINE OUTPUT

UNBALANCED LINE INPUT

UNBALANCED MIC INPUT

10-15V DC INPUT



HALFWAVE ANTENNA

BALANCED LINE LEVEL INPUT

PHANTOM POWER ON/OFF

10-15 V DC OUT