

## SAPPHIRE™ PENDANT MICROPHONE

### *Using Your Charging Cable or Drop-In Charger*

The TeachLogic Sapphire microphone battery can be charged either by using a charging cable (model BRC-15) which plugs in to the bottom charging port on the microphone or by using in a drop-in charging stand (model BRC-60).

When using either method, the insertable plug must be positioned properly and inserted without forcing so hard that the plug or charging port on the bottom of the microphone may be damaged. Take care to learn the right direction for inserting the plug into the microphone or the microphone into the charging stand.

The shape of the plug is not symmetrical, and the cord's plug can go in only one way.



When using a cord to charge the microphone, note that the side of the cord's plug with the USB network symbol should face the same way as the front of the microphone as shown below.



*Note symbol on plug.  
Should face same way as  
front of microphone.*

To make it easy to quickly see what the top of the plug is, we recommend marking it. Correction fluid is one way to do this as shown to the right.



## TeachLogic™ Quick Tips

The BRC-60 Drop-in Charger offers a second way to charge the Sapphire mic (up to 2) as well as a handheld microphone.

To charge the Sapphire:

1. Ensure the lighted “TL” button is facing the front of the charger.
2. Align the charge port on the bottom of the Sapphire over the charge plug inside the BRC-60.
3. Firmly seat the two together.

You should feel the connection and hear an audible “click” when the Sapphire properly connects. **But, the user must take care not to force this connection if alignment is not first made.** The result can be bending or even breaking of the charge port or plug.

